



DC Dome Port Compatibility for Ikelite Housings

This chart provides the correct DC Dome Port option for most current Ikelite compact digital camera housings.

We do not offer adapters for the use of Ikelite DC Dome Ports with housings produced by other manufacturers.

Canon Cameras

	Housing	DC Dome Port	Anti-Reflection Ring
Canon PowerShot G5 X	6146.05	DC2 # 6402	Set # 6407 1/16" + 1/4"
Canon PowerShot G5 X II	6146.06	DC3 # 6403	Set # 6407 1/16" + 1/8" + 1/4"
Canon PowerShot G7 X	6146.07	DC2 # 6402	Set # 6407 1/16"
	6245.07	DC4 # 6404	Not required
Canon PowerShot G7 X II	6146.08	DC4 # 6404	Set # 6407 1/16" + 1/8" + 1/4"
	6245.08	DC4 # 6404	Not required
Canon PowerShot G7 X III	6146.09	DC4 # 6404	Set # 6407 1/16" + 1/8" + 1/4"
Canon PowerShot G16	6146.17	DC3 # 6403	Set # 6407 1/8" + 1/4"
Canon PowerShot G1 X III	6146.18	DC4 # 6404	Not required
Canon PowerShot G1 X II	6146.01 6146.19	Not compatible	-
Canon PowerShot SX700, SX710	6148.70	DC3 # 6403	Set # 6407 1/16" + 1/8"
Canon PowerShot SX720	6148.72	DC3 # 6403	Set # 6407 1/16" + 1/4"
Canon PowerShot SX730	6148.73	DC3 # 6403	Set # 6407 1/16" + 1/8"

Olympus Cameras

	Housing	DC Dome Port	Anti-Reflection Ring
Olympus Stylus 1s	6139.51	DC4 # 6404	Set # 6407 1/8" + 1/4"

	Housing	DC Dome Port	Anti-Reflection Ring
Olympus Tough TG-1, TG-2	6233.01	DC1 # 6401	Not required
Olympus Tough TG-3, TG4	6233.03 6233.04 6233.05	DC1 # 6401	Not required
Olympus Tough TG-5, TG-6	6233.06 6233.07	DC1 # 6401	Not required

Panasonic Cameras

	Housing	DC Dome Port	Anti-Reflection Ring
Panasonic Lumix ZS100, TZ100	6170.10	DC3 # 6403	Set # 6407 1/16" + 1/8"
Panasonic Lumix ZS200, TZ200	6170.12	DC3 # 6403	Not required
Panasonic Lumix ZS50, TZ70	6170.12	DC3 # 6403 Remove hard lens shade	Set # 6407 1/16" + 1/4"
Panasonic Lumix ZS70, TZ90	6170.12	DC3 # 6403	Set # 6407 1/8"
Panasonic Lumix LX10	6171.01	DC4 # 6404	Set # 6407 1/8" + 1/4"
Panasonic Lumix LX100 I, LX100 II	6171.11	DC3 # 6403	Not required

Sony Cameras

	Housing	DC Dome Port	Anti-Reflection Ring
Sony Cyber-shot HX50, HX60	6115.50	DC3 # 6403 Remove hard lens shade	Not required
Sony Cyber-shot HX80, HX90, HX99, WX500	6115.90	DC3 # 6403 Remove hard lens shade	Not required
Sony Cyber-shot RX100 I	6116.10 6116.17	DC2 # 6402	Not required

	Housing	DC Dome Port	Anti-Reflection Ring
	6215.02	DC4 # 6404	Not required
Sony Cyber-shot RX100 II	6116.11 6116.17	DC2 # 6402	Not required
	6215.02	DC4 # 6404	Not required
Sony Cyber-shot RX100 III, IV, IV	6116.12 6116.14 6116.15 6116.16	DC2 # 6402	Not required
	6215.04	DC4 # 6404	Not required
Sony Cyber-shot RX100 VI, VII	6116.18 6116.19	DC3 # 6403	Not required