



Viewfinder Compatibility for Ikelite Housings

This chart provides the correct 45° Magnified Viewfinder option, Type 1, 2, 3, or 4 for most Ikelite Housings for DSLR and Mirrorless Interchangeable Lens (MIL) cameras.

The last column lists compatibility of the Straight Enhanced Magnifying Viewfinder. Up or down refers to the position of the viewfinder in relation to the housing. Some housings may have controls which cause interference with the viewfinder body. “Up” means the viewfinder may be positioned with the eyepiece rotated towards the top of the housing. “Down” means the viewfinder may be positioned with the eyepiece rotated towards the bottom of the housing.

We do not offer adapters for the use of Ikelite Magnified Viewfinders with housings produced by other manufacturer.

Nikon Cameras

| | Housing | 45° Viewfinder | Straight Enhanced Viewfinder Position |
|--------------------------------|--------------------------|----------------|---------------------------------------|
| Nikon D100 | 6810 | Not confirmed | Not confirmed |
| Nikon D200 | 6812 | Not confirmed | Not confirmed |
| Nikon D300 | 6812.3 | Type 1 or 3 | Not confirmed |
| Nikon D3000 | 6801.30 | Not confirmed | Not confirmed |
| Nikon D300S | 6812.31 | Type 1 or 3 | Not confirmed |
| Nikon D3100 | 6801.31 | Not confirmed | Not confirmed |
| Nikon D3200 | 6801.32 | Type 1 or 3 | Not confirmed |
| Nikon D3300 | 6801.33 | Type 1 or 3 | Not confirmed |
| Nikon D3300, D3400 | 6801.34 | Type 1 or 3 | Up or down |
| Nikon D3500 | 6901.35 | Type 1 or 3 | Not confirmed |
| Nikon D40 Nikon D60 | 6804.1 | Not confirmed | Not confirmed |
| Nikon D50 | 6805.1 | Not confirmed | Not confirmed |
| Nikon D500 | 6812.5 71005 73005 | Type 1 or 3 | Up or down |
| Nikon D5000 | 6801.50 | Type 1 or 3 | Not confirmed |
| Nikon D5100 | 6801.51 | Type 1 or 3 | Not confirmed |
| Nikon D5200 | 6801.52 | Type 1 or 3 | Not confirmed |
| Nikon D5300 | 6801.53 | Type 1 or 3 | Not confirmed |
| Nikon D5500, D5600 | 6801.55 | Type 1 or 3 | Not confirmed |
| | 6901.56 | Type 1 or 3 | Not confirmed |
| Nikon D600, D610 | 6812.6 6812.61 | Type 2 | Not confirmed |

| | Housing | 45° Viewfinder | Straight Enhanced Viewfinder Position |
|----------------------------|-----------------------------|----------------|---------------------------------------|
| Nikon D70 | 6807 6807.1 | Type 2 | Not confirmed |
| Nikon D700 | 6812.7 | Type 1 or 3 | Not confirmed |
| Nikon D7000 | 6801.70 | Type 2 | Not confirmed |
| Nikon D7100, D7200 | 6801.71 6801.72 71001 | Type 2 | Up or down |
| Nikon D750 | 6812.75 71007 | Type 1 or 3 | Up or down |
| Nikon D7500 | 71017 | Type 2 | Up or down |
| Nikon D780 | 6891.3 | Type 3 | Up or down |
| Nikon D80 | 6808.1 | Not confirmed | Not confirmed |
| Nikon D800 | 6812.8 71011 | Type 1 or 3 | Up or down |
| Nikon D810 | 6812.81 71009 | Type 1 or 3 | Up or down |
| Nikon D850 | 71015 | Type 1 or 3 | Up or down |
| Nikon D90 | 6809.1 | Type 2 | Not confirmed |
| Nikon Z5 | 71067 | Type 3 | Up or down |
| Nikon Z6, Z6 II, Z7, Z7 II | 71063 | Type 3 | Up or down |
| Nikon Z50 | 71065 | Type 3 | Up or down |

Canon Cameras

| | Housing | 45° Viewfinder | Straight Enhanced Viewfinder Position |
|----------------------|---------|----------------|---------------------------------------|
| Canon 1000D Rebel XS | 6872.10 | Not confirmed | Not confirmed |

| | Housing | 45° Viewfinder | Straight Enhanced Viewfinder Position |
|---------------------------------------|--------------------|----------------------------|---------------------------------------|
| Canon 100D Rebel SL1 | 6970.01 6970.03 | Type 1 or 3 | Up or down |
| Canon 200D Rebel SL2 | 6970.05 6970.06 | Type 1 or 3 | Up or down |
| Canon 250D Rebel SL3 | 6970.08 6970.09 | Type 1 or 3 | Up or down |
| Canon 10D | 6871.10 6871.11 | Type 1 or 3 | Not confirmed |
| Canon 1100D Rebel T3 | 6872.11 | Not recommended | Not confirmed |
| Canon 1200D Rebel T5 | 6872.12 | Not recommended | Not confirmed |
| Canon 20D | 6871.20 | Type 1 or 3 | Not confirmed |
| Canon 300D Rebel | 6870 6870.1 | Not confirmed | Not confirmed |
| Canon 30D | 6871.30 | Type 1 or 3 | Not confirmed |
| Canon 350D Rebel XT | 6871.35 | Not confirmed | Not confirmed |
| Canon 400D Rebel XTi | 6871.40 | Not confirmed | Not confirmed |
| Canon 40D | 6870.40 | Type 1 or 3 | Not confirmed |
| Canon 40D, 50D | 6870.50 | Type 2 | Not confirmed |
| Canon 450D Rebel XSi | 6871.45 | Type 2 Limited rotation | Not confirmed |
| Canon 500D Rebel T1i | 6871.50 | Type 2 Limited rotation | Not confirmed |
| Canon 550D Rebel T2i | 6871.55 | Type 2 | Not confirmed |
| Canon 5D | 6871.05 | Type 1 or 3 | Not confirmed |
| Canon 5D Mark II | 6871.02 71700 | Type 1 or 3 | Up only |
| Canon 5D Mark III Canon 5DS, 5DS R | 6871.03 6871.04 | Type 2 | Down only |

| | Housing | 45° Viewfinder | Straight Enhanced Viewfinder Position |
|--|---------------------------|----------------|---------------------------------------|
| Canon 5D Mark III, Mark IV Canon 5DS, 5DS R | 6871.09 71702 73702 | Type 2 | Down only |
| Canon 600D Rebel T3i | 6871.60 | Type 2 | Not confirmed |
| Canon 60D | 6870.60 | Type 2 | Not confirmed |
| Canon 650D Rebel T4i | 6871.65 | Type 2 | Not confirmed |
| Canon 6D | 6871.06 71706 | Type 2 | Down only |
| Canon 6D Mark II | 71720 | Type 2 | Down only |
| Canon 70D | 6870.70 | Type 2 | Not confirmed |
| Canon 700D Rebel T5i | 6871.65 | Type 2 | Not confirmed |
| Canon 750D Rebel T6i | 71718 | Type 2 | Down only |
| Canon 7D | 6871.07 71704 | Type 2 | Down only |
| Canon 7D Mark II | 6871.08 71708 | Type 2 | Down only |
| Canon 80D | 6870.80 71710 | Type 2 | Down only |
| Canon 850D Rebel T8i | 71728 | Type 2 | Not confirmed |
| Canon 90D | 71726 | Type 2 | Up or down |
| Canon M5 | 6973.05 | Type 1 or 3 | Up or down |
| Canon R | 71760 | Type 3 | Up or down |
| Canon R5 | 71764 | Type 3 | Up or down |
| Canon R6 | 71766 | Type 3 | Up or down |
| Canon R7 | 69746 | Type 4 | |
| Canon R10 | 69742 | Type 4 | |

| | Housing | 45° Viewfinder | Straight Enhanced Viewfinder Position |
|----------|---------|----------------|---------------------------------------|
| Canon RP | 71762 | Type 3 | Up or down |

Olympus, Panasonic, Sony Cameras

| | Housing | 45° Viewfinder | Straight Enhanced Viewfinder Position |
|--------------------------------|------------------|----------------|---------------------------------------|
| Olympus E-1 | 6851 | Not confirmed | Not confirmed |
| Olympus E-3 | 6851.3 | Not confirmed | Not confirmed |
| Olympus E-30 | 6852.30 | Not confirmed | Not confirmed |
| Olympus E-300 | 6853 | Not confirmed | Not confirmed |
| Olympus E-330 | 6853.30 | Not confirmed | Not confirmed |
| Olympus E-410 Olympus E-420 | 6854.10 | Type 2 | Not confirmed |
| Olympus E-500 | 6855 | Not confirmed | Not confirmed |
| Olympus E-510 Olympus E-520 | 6856.20 | Not confirmed | Not confirmed |
| Olympus OM-D E-M1 II | 6952.02 69532 | Type 1 or 3 | Up or down |
| Olympus OM-D E-M1 III | 6952.03 | Type 1 or 3 | Up or down |
| Olympus OM-D E-M5 | 6950.51 | Type 2 | Not confirmed |
| Olympus OM-D E-M5 II | 6950.52 | Type 1 or 3 | Not confirmed |
| Olympus OM-D E-M10 | 6950.10 | Type 1 or 3 | Not confirmed |
| Olympus OM-D E-M10 II | 6950.12 | Type 1 or 3 | Up or down |
| Olympus OM-D E-M10 III | 69531 | Type 1 or 3 | Up or down |

| | Housing | 45° Viewfinder | Straight Enhanced Viewfinder Position |
|--|------------------|----------------|---------------------------------------|
| OM System | 69540 | Type 3 | Up or down |
| Panasonic G9 | 71307 | Type 1 or 3 | Up or down |
| Panasonic G85 Panasonic G80 | 6961.08 | Type 1 or 3 | Up or down |
| Panasonic GH3 Panasonic GH4 | 6860.03 | Type 1 or 3 | Not confirmed |
| Panasonic GH5, GH5 II | 71305 71311 | Type 1 or 3 | Not compatible |
| Panasonic S5 | 71309 | Type 1 or 3 | Down only |
| Samsung NX1 | 6821.01 | Type 2 | Not confirmed |
| Sony A1 | 71476 | Type 1 or 3 | Up only |
| Sony A7, A7R, A7S | 6843.71 71471 | Type 1 or 3 | Up only |
| Sony A7 II, A7R II, A7S II | 6843.72 71472 | Type 1 or 3 | Up only |
| Sony A7R III, A9 | 71473 | Type 1 or 3 | Up only |
| Sony A7R IV | 71474 | Type 1 or 3 | Up only |
| Sony A7S III | 71475 71476 | Type 1 or 3 | Up only |
| Sony A100 | 6841 | Not confirmed | Not confirmed |
| Sony A200 | 6841.20 | Not confirmed | Not confirmed |
| Sony A300 Sony A350 | 6841.35 | Not confirmed | Not confirmed |
| Sony A230 Sony A330 Sony A380 | 6841.38 | Not confirmed | Not confirmed |
| Sony A700 | 6841.7 | Not confirmed | Not confirmed |

| | Housing | 45° Viewfinder | Straight Enhanced Viewfinder Position |
|------------------------------------|----------------|-----------------------|--|
| Sony A33 Sony A55 | 6842.55 | Type 1 or 3 | Not confirmed |
| Sony A57 Sony A65 | 6842.65 | Type 1 or 3 | Not confirmed |