



## W-30 Wide Angle Wet Lens

Item number 6430

### Included in the Box

- W-30 lens
- Neoprene cover # 0200.5
- Rear cover # 0200.95
- Silicone lubricant 1cc tube

### Installation and Use

#### Attaching the Lens

1. Remove the neoprene lens cover.
  2. Inspect the threads of the lens and housing port to see that they are free of dirt or debris.
  3. Apply a small amount of silicone lubricant to the threads of the lens.
  4. Gently rotate the lens clockwise into the front of the port or adapter and tighten snugly.
- » **Do not over-tighten or use excessive force when connecting the lens.**
- » **Do not cross-thread lens. Cross-threading the lens may damage the lens and/or port. If the lens does not thread easily, remove and inspect threads before trying again**

#### Using the Lens Underwater

1. Once underwater, remove the lens and gently flush any bubbles away from the front and back of the lens, and the front of the housing's port.
2. Zoom the camera to full wide angle. If vignetting (dark shadows around the edges of the image) occurs, zoom in slightly until the vignetting is eliminated. Alternatively, the vignetting may be removed by cropping your images in post production.

3. Remove the lens for shooting close up macro subjects. Store the lens securely in a lens holder or BCD pocket when not in use.
- » **The W-30 lens contains high quality ground glass and is negatively buoyant. The lens will sink quickly if not secured properly underwater.**

### Maintenance and Storage

#### Post-Dive

1. Remove the lens from the housing and rinse the front, back, and sides of the lens with fresh water immediately after leaving the water.
  2. Dry the lens with a clean, lint-free lens cloth.
  3. Replace the neoprene lens cover.
  4. Store in a cool, shaded area.
- » **Water droplets may damage the lens coating if left to dry on the lens. Damage to the lens coating is not repairable.**
- » **Do not dry the lens with a hair dryer, heater, radiator, etc. Use only a soft lens cloth.**
- » **Do not store or travel with the lens attached to the housing.**

### Limited Warranty

This Ikelite product is warranted against any manufacturing defects for a period of one (1) year from the original date of purchase. To obtain warranty service, the product must be returned to Ikelite postage paid. Ikelite will, at its sole discretion, repair or replace such products, and will return to customer postage paid. All other claims of any nature are not covered. Except as mentioned above, no other warranty expressed or implied applies to this Ikelite product.

### Contact Us

Ikelite Underwater Systems  
50 W 33rd St  
Indianapolis, IN 46208 USA  
(317) 923-4523  
ikelite@ikelite.com