



1887.6 Tray Mount Kit for Gamma

Assembly Instructions

See **Diagram A** - reverse side

1. Tighten the Thumb Screw onto the Tray (*finger-tighten only*).
 2. Place the Black Nylon Washer on the 1/4-20 x 7/8" Screw and slide through the mounting hole. Hold the screw head against the tray with one hand. With your other hand, push the Flex Mount onto the 1/4-20 x 7/8" Screw and over the Thumb Screw head.
 3. Slide Lock Washer over screw and hand tighten Nut. For more stability, finish tightening with a nutdriver or socket wrench, and a flathead screwdriver.
 4. Apply a thin film of lubricant to attachment points as shown in Diagram A.
 5. Press each component together.
 6. Loosen Mount Strap and insert Gamma Light (*not included*); retighten.
M27 Gamma Diffuser is included and threads onto the Gamma front to spread out the beam for use as a video or focus assist light. Lanyard Included.
- For additional arm length, attach the 3/4" arm extension between the Flex Mount and 1/2"-3/4" Adapter.

Ikelite Underwater Systems
50 West 33rd Street
Indianapolis, IN 46208 USA
www.ikelite.com

Diagram A

