



DLM Port Extension

Product numbers 5516.65 • 5516.67 • 5516.69 • 5516.70

Included in the Box

- Port extension
- O-ring # 0132.36
- Silicone lubricant # 0184.1

Installation and Use

Attaching the Extension to a Port

1. Using your fingers or a 7/64" hex key, loosen each Thumbscrew until at least 4 threads are visible.
2. Make sure the port Sealing Surface is clean and free of debris.
3. Clean and lightly lubricate the O-ring. Apply an even coating of lubricant, just enough to make the o-ring slightly shiny. Avoid dry spots or excess build-up of lubricant.
4. Line up the thumbscrews on the port and extension. Firmly press components together until they are flush around the circumference.
5. Tighten each thumbscrew until it stops. DO NOT over-tighten.
6. Attach the complete port with extension to your housing.

Travel and Storage

1. Remove the extension from the Port and Housing Port Base for long-term storage.
2. Lightly lubricate the o-ring prior to storage. The o-ring may be left on the extension, or stored separately in a resealable plastic bag.
3. Store in a cool, dry place.

Limited Warranty

This Ikelite product is warranted against any manufacturing defects for a period of one (1) year from the original date of purchase. To obtain warranty service, the product must be returned to Ikelite postage paid. Ikelite will, at its sole discretion, repair or replace such products, and will return to customer postage paid. All other claims of any nature are not covered. Except as mentioned above, no other warranty expressed or implied applies to this Ikelite product.

