



Zoom/Focus Gear Set 5509.16

Item number 5509.16

Included in Box

- Zoom gear
- Zoom clamp

Installation and Use

Attaching the Sleeve and Clamp to a DL Housing

1. Place the zoom gear into the housing port mount opening with gear slots facing up.
2. Gently align the zoom gear teeth with small black gear inside of housing.
3. Tighten the zoom gear retainer into the port mount using the zoom gear retainer tool (included with the housing). Tighten clockwise so the retainer is snug. Do not overtighten.
4. Line up the two white dots on the camera face and lens, and bayonet the lens into the camera body by rotating the lens counterclockwise.
5. Gently expand and place the clamp over the front of the lens.
6. Line up the clamp tabs with the zoom gear slots.
7. Push clamp down on the lens until the tabs slide into the slots.
8. Check zoom function.
9. Install the lens port.

Limited Warranty

This Ikelite product is warranted against any manufacturing defects for a period of one (1) year from the original date of purchase. To obtain warranty service, the product must be returned to Ikelite postage paid. Ikelite will, at its sole discretion, repair or replace such products, and will return to customer postage paid. All other claims of any nature are not covered. Except as mentioned above, no other warranty expressed or implied applies to this Ikelite product.

